


PARTS LIST


Shift knob

**INSTALLATION**

1. Remove the shift knob by rotating it counterclockwise. Set the knob aside, it will not be reused.



2. Install the new shift knob by turning it clockwise. Turn the knob until the orientation of the shift pattern is correct. The knob should turn 10 to 14 times.

**USE AND CARE**

- Use a sponge or cloth and a solution of mild liquid dishwashing soap and water to clean the shift knob.
- Rinse the knob completely with water, then dry it with a shop towel.
- Never use organic solvents such as benzene, thinner, or gasoline to clean the shift knob.